

Sushezi™
SUSHI MAKER



Ezidri
HOME FOOD
DEHYDRATORS



EziVac
VACUUM PACKAGING
SYSTEM



Apple Peeler Corer Slicer

Slinky Machine

INSTRUCTIONS



Instructions

Congratulations on the purchase of your very own Apple Peeler Corer Slicer.

This fantastic Slinky Machine is so easy to use that you will be a Slinky expert in no time.

Alternative Uses

The Apple Peeler Corer Slicer can also be used for other fresh produce such as pears, potatoes, beetroot, cucumber & more.

Handy Hints

- ★ Only fresh fruit should be used as over-ripe or very soft fruit does not handle well.
- ★ Apple Juice is very sticky once it has dried so we recommend that the Apple Peeler Corer Slicer is wiped thoroughly after use to maintain the condition of the unit.
- ★ To avoid rusting, please make sure the Apple Peeler Corer Slicer is clean and dry after use.

Warranty

The Apple Peeler Corer Slicer comes with a 12 month warranty against manufacturing faults.



Step 1

Place the machine on an even work area with the handle on your right. Rotate lever (A) counter clockwise (from right to left) to engage the rubber suction base.

Step 2

Push lever (B) away from you with your left hand while using your right hand pull the handle (C) to your right.

Step 3

Holding the main shaft (J) with your left hand unwind the handle (C) with your right hand and turn the handle (C) around, as shown in the picture above and screw back onto the shaft.

Step 4

Take your prong (D) and wind onto the end of the main shaft (J) as shown in the picture above.

Step 5

Make sure the coring blade (G) is set to the centre of the main shaft (J) so that the prong (D) can fit through the coring blade (G) without touching. This can be adjusted by loosening the wing nut (F) and moving the coring blade until the prong (D) fits through and then tighten the wing nut (F).

Step 6

To put the machine into start position, push lever (B) away from you with your left hand while using your right hand pull the handle (C) to your right.

Step 7

Remove the apple stalk then place your produce onto the prong as far as it goes. The produce must be centred on the shaft for proper operation of the peeler & corer.

Step 8

To adjust the thickness of the peel, adjust the depth of the peeler blade (I), using the screw.

Step 9

Turn handle continuously as far as you can, then remove the Slinky and Enjoy!

To Leave Peel On

To leave the peel on your produce simply pull the peeler blade arm (H) towards your body and apply the silver lever (E).

To Peel Without Slicing

To peel your produce without coring & slicing, simply loosen the wing nut (F) & drop the coring blade (G) away from the shaft (J).

